



Broadband transformer turns not critical  
 All .1 are .1uF and can be anything from .01uf to .1uF  
 Most application will have VCC=12V and tie BIAS and VCC together  
 Separating BIAS and VCC allows for shaped keying in an RF transmit chain.  
 Key issue is to bias NPN for at least 10mA to get high enough gm so that  
 the circuit actually works as a feedback amp  
 Transistor type not critical.  
 Try to use ft of 300 MHz or higher.  
 Good transistor choices are 2N3904 2N2222A 2N5109 2N3866  
 MPSH10 is good NPN as long as you remember to bend the leads  
 properly (MPSH10 does not share 2N3904 standard BCE sequence)  
 Parallel transistors in schematics are only for setting up the layout.  
 Use just one transistor.

Module: Broad Band Feedback Amp

Reference: Experimental Methods in Radio Frequency Design (ARRL)  
Chap 2.4

WA7MLH  
www.neoanderthal.com

MOD_BB_AMP1.sch	
Sheet: /	
File: MOD_BB_AMP1.sch	
<b>Title:</b>	
Size: A4	Date:
KiCad E.D.A. kicad 4.0.2-stable	
<b>Rev:</b>	
Id: 1/1	